

**TABLE OF CONTENTS
FOR
HUD MAINTENANCE GUIDEBOOKS
GUIDEBOOK III - PAINTING MAINTENANCE**

SEPTEMBER 1994

CHAPTERS	Pages
1 INTRODUCTION	
A General	1-1
B The Purpose of Paints and Coatings	1-1
C When Not to Paint	1-2
D When to Paint	1-2
E Inspection Procedures	1-3
F Planning Procedures	1-3
G Preventive-Maintenance Inspections	1-4
H Maintenance Painting	1-5
I HUD Guide	1-8
J Compliance with Safety Regulations	1-8
K Lead-Based Paint Abatement and Management	1-10
L Painting Program Record-Keeping	1-11
2 SURFACE PREPARATION	
A Purpose of Surface Preparation	2-1
B Substrates	2-1
C Surface Preparation Materials and Methods	2-2
3 PAINTS AND COATINGS	
A The Composition of Paints	3-1
B Generic Descriptions of Paints and Coatings	3-2
C Types and Uses of Various Paints and Coatings	3-2
D Interior Paints and Coatings	3-6
E Exterior Paints and Coatings	3-6
4 APPLICATION PROCEDURES	
A Application Procedures for Exteriors	4-1
B Application Procedures for Interiors	4-5
5 POST-PAINTING PROCEDURES	
A Clean-up Procedures	5-1
B Waste Removal	5-1
6 PAINT PROBLEM-SOLVING	
A Generalized Paint Failures	6-1
B Localized Paint Failures	6-1
C Surface Problems	6-1
D Problem-Solving Resources	6-4
BIBLIOGRAPHY	BIBL-1
GLOSSARY	GLOSS-1

END OF TABLE OF CONTENTS